

状态①: K1跳空(常闭) ① 操作①: 用左手将跳空(常闭)开关推向表壳 	状态②: K1跳空(常闭) ① ② 操作②: 用右手缓慢拨动指针超过(K1)10℃ 	状态③: K1跳空(常闭) ① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩ 操作③: 缓慢移开左手, 右手维持不动 	状态④: K1正常(常开) ① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩ 操作④: 右手缓慢回调指针直至开关恢复常开 
---	---	---	---